



**RAWHIDE**

**Portable Corral**  
SYSTEM

*1 Person*

*No Lifting*

*10 Minutes*



## Frame Setup Procedure

- 1) Always unhook from vehicle on solid, level ground for safe, easy setup.



- 2) Lower front hitch jack all the way down to ground. It is important to do this before continuing. The front frame must make solid contact with the ground to stabilize the unit before further setup.



- 3) Raise rear frame with electric lift while front frame continues making full ground contact.



- CAUTION:** Do not raise rear frame until front frame is completely lowered and making full ground contact.



- 4) Continue to raise frame until both wheels are off ground.



- 5) With both wheels raised and front frame making ground contact remove both wheels by removing axle pins and sliding off.



- 6) After removing both wheels, lower frame with electric lift until full contact with ground. Now you're ready to begin corral setup.



## Two Models Available

Standard

Large

# Corral Setup Procedure

- 1) Unchain panels and pull. No lifting required.



- 2) Roll out gate and first panel at 90°



- 3) Pull and roll out next set of three panels from frame. Then push from the inside out. Let the wheels do the work.



- 4) Extend then separate and roll next panel out.




- 5) Unfold last panel and roll around to connect to first panel to complete one side.



- 6) Do the same on the other side and you're done in about ten minutes.



For added panel stability, use support bars. Raise, pull out, and insert in ground. That's it.



Every panel folds in, except for the third—it folds out.

## Rawhide Corral Advantages

- Fast, 10 minute set up.
- Labor Free.
- More capacity than competitor.
- Multiple pen options.
- Can enter and exit at opposite ends with pick up truck.
- Pulls at speed limit in transport.
- All panels work like gates.
- Saves labor cost.
- Less expensive per square foot than competitors' corral.
- Durable equipment, much longer life than most livestock panels
- Not limited, equipment can be added or moved around system.
- Largest capacity corral on wheels.
- Up to 300 head capacity available.
- Easy alternative for future cattle identification requirements, on-site temporary working facility.



## Features

- 4 man-pass gates, no climbing
- No lifting, hydraulic jack does that
- 2 bow gates for sorting
- 10—20' sections, 1—13' panel
- 22' long main frame with palpation gate
- 2—16" wheels
- Chain on end panels
- 2" pipe braces
- Solid rubber wheels
- 12V Charging Plug

## Dimensions

- 10—20' x 5'8" panels
- 1—13' x 5'8" panel
- 1—10' x 10' bow gate
- 1—8' x 8' bow gate
- 2—18" man-pass gates
- 1—26" man-pass gate
- 2—28" alley gates

## Material

- 2" round
- 3" x 3" square, 3/16" thick frame
- 2" schedule 80 pipe



- **Pinning system allows for uneven terrain**
- **Pinning system allows panels to fold back flush to each other without unpinning from one another.**



- **Initially, fold open to one large pen for catching cattle.**
- **22' wide at the narrowest**
- **128' long (standard) when open**
- **Entire system can be driven completely through with dually pickup, with round bale.**

- Up to 300 head
- Pulls speed limit on highway
- Fits in same gate as pick up
- Stable on uneven terrain
- Self-contained power unit/battery
- Frame gates for sorting
- Wheels on each panel
- Electric over hydraulic jack
- 300 head systems and 2 different sizes available
- Hydraulic Tongue Jack

## Rawhide Portable Corral

307 Augustine Avenue  
Abilene, Kansas 67410

(785) 263-3436

[www.rawhideportablecorral.com](http://www.rawhideportablecorral.com)

